BNP 250 & 260 Wetblast Cabinets

SLA Applications

- Smooth build lines from SLA masters while improving surface finish and decreasing handwork
- Deflash corners of molded parts
- Clean gummy residue from corners
- Reduce RTV inhibition

General Industry Applications

- Clean/texture parts with minimal impregnation of blast media
- · Finish delicate parts
- Prep for bonding
- Finish metal parts to produce a smooth surface and bright appearance
- Finish metal parts to achieve a low Ra surface
- Clean/finish electrical components sensitive to static electricity
- Clean investment castings
- Strip paint from fiberglass parts
- Remove heat scale or oxidation

BlastMedia

Wetblast cabinets can be used with many types of blast media but most commonly with glass bead and aluminum oxide, or a mix of the two. The best choice for a given application is determined through trial and error.



ZERO BNP Wetblast cabinets deliver affordable, dust-free media blasting to efficiently clean and finish all kinds of parts. The wetblast process produces a smooth surface, a bright shine, and does not produce static electricity commonly an issue in dry blast operations. The rinsing action produces cleaner parts than dry blast

BNP Wetblast Cabinets feature: Safety

- Dust-free wetblasting reduces worker exposure to dust. Eliminates static electricity build-up generated by dry blasting.
- Safety interlocks interrupt blasting if either door is opened.
- Double-wall, sound-insulated doors reduce noise.

Productivity

- Fluorescent lighting brightly illuminates work chamber.
- Generous 12.5" by 19.5" window gives operator commanding view.
- 150-cfm exhauster maximizes visibility inside cabinet.
- Operator-controlled domestic-water wash system maintains clean window for clear view of work inside.
- Foot pedal activates blast process and minimizes operator fatigue.
- Fingertip-activated rinsing control speeds work flow.

Performance

- 14-gauge stainless steel cabinet and grating provide rust-free blasting environment.
- Pressure regulator with gauge is within easy reach on light module. Toggle switches activate lighting, exhauster, and diaphragm pump.
- Diaphragm pump ensures ready supply of media/water to maintain efficient work flow.
- Adjustable, heavy-duty chrome latches seal doors tight through years of service.

Clean Peen Deburr Finish



BNP Blast Gun with Ceramic Nozzle

ZERO's BNP gun sets the industry standard for durability, versatility, and performance. Its proven, ergonomic grip reduces operator fatigue and increases productivity. The standard 5/16inch ceramic nozzle is perfect for light-industrial glass bead applications. *Optional* tungsten nozzles offer much greater wear life than ceramic. Boron carbide nozzles can be used with aggressive media, when the cabinet is fitted with an aggressivemedia-resistant pump.

Industries Served

- Aerospace
- Automotive Manufacturing
- Automotive Rebuilding
- Aircraft Component Manufacturing
- Rapid Prototype and Manufacturing Services
- Medical Instrument Manufacturing
- Public Utilities
- Military

work flow.

S P E C I F I C A T I O N S

COMPLETE SYSTEM

Actual space required depends on desired work flow. Allow additional work space for operator and maintenance access.



CABINET

BNP 250	BNP 260		
Working Chamber Size	Working Chamber Size		
35" deep (914 mm) 36" wide (889 mm) 37" high (940 mm)	39" deep (990 mm) 50" wide (1270 mm) 43" high (1092 mm)		
Window Size (safety glass)	Window Size (safety glass)		
19.5" wide (495 mm) 12.5" high (318 mm)	19.5" wide <i>(495 mm)</i> 12.5" high <i>(318 mm)</i>		
Door Opening	Door Opening		
- 22.5" (0:00mm) (0:00m	277 miles (680mm) (680mm) (750 miles (750 mi		
Overall System Dimensions	Overall System Dimensions		
49" deep (1245 mm) 39" wide (991 mm) 73" high (1854 mm)	53" deep (1346 mm) 56" wide (1422 mm) 82" high (2082 mm)		
ME	DIA		
The DND Wethlast askingto and designed for use with place hand			

The BNP Wetblast cabinets are designed for use with glass bead media up to 50-mesh (U.S. Sieve); MilSpec #6 or smaller. Aluminum oxide or other aggressive media can be used when the cabinet is equipped with *optional* aggressive-media pump.

WATER

The BNP Wetblast cabinets utilize a diaphragm pump to recirculate the media-water slurry. After an initial charge of water and media, clean water is added only when the parts-wash or window-wash control is activated. Connects to 1/2" ID water hose.

AIR CONSUMPTION

BNP GUN	NOZZLE ORIFICE	AIR JET	CFM at 80 PSI
No. 4	5/16"	1/8"	21
No. 5	5/16"	5/32"	32
No. 6	3/8"	3/16"	47

ELECTRICAL SUPPLY

1/3 HP, 115/208-230v motor (wired for 115v), 1 Ph, 60 Hz; GFCI required. Optional: 50 Hz Electrics

ORDERING INFORMATION

Model	Stock	Shipping
Number	Number	Weight
BNP 250 (glass bead media)	12951	625 lbs (283 kgs)
BNP 250 (aggressive media)	24429	850 lbs (386 kgs)
BNP 260 (glass bead media)	24742	750 lbs (337 kgs)
BNP 260 (aggressive media)	24743	970 lbs (440 kgs)

Distributed By:

ISO 9001 certified. Clemco is committed to continuous product improvement. Specifications are subject to change without notice.

© 2017 Clemco Industries Corp. • Washington, MO 63090 • 636 239-4300 • FAX 800 726-7559

info@clemcoindustries.com • www.clemcoindustries.com